

Radio Mic Frequency Sets

Channel 38 Radio mic Frequency Sets

Please note these sets are not guaranteed to work at any given location and therefore should be used as a guide. The radio mics can be re-tuned to any frequency within 606-500 – 613-500 MHz

Up to 10 mics	12 mic set	16 mic set
Frequency	Frequency	Frequency
606.600	606.500	606.500
607.500	606.875	606.900
608.150	607.375	607.275
609.150	608.000	607.900
609.950	608.425	608.325
610.550	609.325	608.825
611.250	609.775	609.325
612.300	610.475	609.775
613.150	611.000	610.375
613.500	611.400	610.900
	612.000	611.300
	613.275	611.700
		612.100
		612.500
		613.000
		613.500

Paddle Kit Wiring

If using two racks, via one paddle kit wire as follows

1. Link BNC B on rack one to BNC Link on rack two
2. Link BNC B on rack two to BNC Link on rack one
3. Wire the paddles to BNC A on both racks

Radio Mic Frequency Sets

Channel 70 Frequency Sets

Up to 6 channels
863.100
863.400
863.750
864.225
864.550
864.975